



Correct assembly for silent drag pawl & cam

Ensure that Drag pawl pin is inside of silent drag cam slot or reel will click when winding.

Spring should be in front of pin for correct operation of the drag.

When assembling spool to reel have drag in OFF position.

Key	Part	Description	Key	Part	Description
1	R6E2	Spindle Screw Set	10	R7A2	Drag Friction Tube
2	R7E3	Handle Plate Assy	11	R7J9	Pawl
3	R7F1	Handle Plate Lock Nut	12	R5G4	Drag Pawl Spring
4	R7D3	Star Drag Nut	13	R7K9	Drag Knob Assy
5	R4A	Spool Only	14	R6A22	Spindle
6	R7B/C3	Drag Washer Set	15	R6J7	Spindle Washer
7	R7L3	Silent Drag Cam	16	R5E9	Fish Alert Button
8	R5B6	Fish Alert Wheel	17	R6F1	Spindle Hex Nut
9	R7H4	Friction Tube Washer			

45BC / (SD)

Special Note: The 45BC cannot be converted from right hand wind to left hand wind. A left hand wind version is available. Please contact your local tackle dealer.