



6000C8

Key	Part	Description	Key	Part	Description
1	R6E2	Spindle Screw Set	13	R7H1	Drag Lever Springl
2	R7F1	Handle-plate Lock Nut	14	R5G3	Drag Pawl Spring
3	R7E26	Handle-plate Assy	15	R7J10	Drag Pawl
4	R7D12	Tristar Drag Nut	16	R5E6	Ratchet Assembly
5	R7B/C25	Friction Washer Set	17	R7K2	Drag Knob & Wheel
6	R4A	Spool Only	18	R5C2	Drag Lever & Rivet
7	R7L3	Silent Drag Cam	19	R6F3	Dome Nut
8	R5B4	Fish Alert Wheel	20	R2G9	Base Lock Spring
9	R7H4	Friction Tube Washer	21	R2DEF2	Base Bolt Assembly
10	R7A9	Friction Tube	22	R2H1	Lever & Rivet
11	R6A17	Spindle	23	R2A1	Index Plate Assembly
12	R6J1	Spindle Washer	24	R1A	Back Assembly