



| Key | Part | Description | Key | Part | Description |
|-----|---------|-----------------------|-----|--------|----------------------|
| 1 | R6E4 | Spindle Screw Set | 15 | R7M3 | Drag Pawl Rivet |
| 2 | R7F2 | Handle-plate Lock Nut | 16 | R5H1 | Drag Lever Spring |
| 3 | R4F5 | Rapid Handle Assy | 17 | R5G3 | Drag Pawl Spring |
| 4 | R4F7 | Power Handle Assy | 18 | R7J4 | Drag Pawl |
| 5 | R7E21 | Handle-plate Assembly | 19 | R5E6 | Ratchet Assembly |
| 6 | R7D11 | Drag Tension Star | 20 | R5C2 | Drag Lever & Rivet |
| 7 | R7B/C5 | Drag Washer Set | 21 | R7K2 | Drag Knob & Wheel |
| 8 | R4A-700 | Spool Only | 22 | R6F3 | Dome Nut |
| 9 | R7L1 | Silent Drag Cam | 23 | R2G11 | Base Lock Spring |
| 10 | R5B5 | Fish Alert Wheel | 24 | R2DEF2 | Base Bolt Assembly |
| 11 | R7H1 | Friction Tube Washer | 25 | R2H2 | Lever & Rivet |
| 12 | R7A4 | Friction Tube | 26 | R2A6 | Index Plate Assembly |
| 13 | R6A12 | Spindle | 27 | R2M1 | B/L Spr Screw & nut |
| 14 | R6J5 | Spindle Washer | | | |

700C5RR