


825BCV 04

PARTS LIST



Key	Part	Description	Key	Part	Description
1	R6E4	Spindle Screw Assy	13	R5B5	Fish Alert Wheel
2	R7F3	Lock Nut Retainer	14	R7A4	Drag Friction Tube
3	R7F2	H/plate lock nut	15	R7H1	F/Tube Washer
4	R4F7	Handle Assy	16	R6A18	Spindle
5	R4H2	Handle Plug	17	R5C7	On/Off Lever Assy
6	R4E9	Handle Screw	18	R7J4	Drag Pawl
7	R4D4	Handle Only	19	R5G3	Drag Pawl Spring
8	R4G2	Handle Lock Nut	20	R5K2	Drag On/Off Cam
9	R7E18	Handle Plate Assy	21	R5E10	Fish Alert Assy
10	R7D11	Star Nut	22	R6J10	Spindle Washer
11	R7BC15	Clutch Washer Set	23	R6F3	Dome Nut
12	R7L1	Silent Drag Cam	24	R2C5	Base & Screws

\* 825BCVMWG PARTS LIST(+ ABOVE)

Part No	Part Description
D2A RC	STAINLESS STEEL BASE CLAMP